

Glen Carbon Centennial Library

Computer Support Guide for the Bring in the Arts kiosks

To Get Access to the Macintosh Mini

- 1) Open the back of the kiosk...



2) Connect your Apple Keyboard and Mouse

1) Connect the Apple Keyboard and Mouse to the USB ports of the Macintosh Mini.




3) Use a mousepad or other non-reflective surface for the mouse

The kiosk surface is highly reflective.


1) Place a mousepad or other non-reflective surface under the mouse for significantly better performance.




4) Hit the ESC (Escape) key (repeatedly) to quit the kiosk application




5) Once you quit the kiosk application, you will see the Macintosh Desktop.
You now have access to your Macintosh Mini and Apple OS 10.5



6) From System Preferences, you can adjust many computer settings. We'll use Sound in this example.



7) The Sound Control Panel allows you to adjust the volume level the Macintosh Mini sends to the speakers.



8) Close the Sound Control panel by clicking on the **red dot**.

9) To restart the kiosk

